




Ref No	Part No	Description
1	5L2100	Pistol Housing
2	2C2003	Blank Cap
2-1	7Q2008	O Ring
3	7Q2006	O Ring (2)
4	7Q6112	Valve O-Ring
5	6S2023	Valve Pin
6	6N2106	Cone Spring
7	6S2024	Valve Bushing
7-1	7Q2009	O Ring (2)
8	5L2601	Lock Pin
9	7S2106	Set Screw
10	5L2701	Button
10-1	6S2032	Lock Plate Screw
10-2	6S2025	Lock Plate
11	7Q2011	Valve O-Ring
11-1	6N5006	Spring
12	2P6001	Valve
13	7S2107	Set Screw And Washer
14	2L6012	Switch
15	7S5001	Ball Bearing
16	1S6001-A	End Plate
17	1P6005	Cylinder
17-1	2S2023	Key
18	1S6046	Rotor
19	1P6051	Blade (6)
20	1P3012	Front Plate
21	7S2002	Ball Bearing
23	1P2274	First Main Gear
24	1P2110	First Plant Gear (4)
25	1P2280	First Gear Cage
26	1G6090	Second Main Gear
27	1P6130	Second Plant Gear (4)
28	1P2295	Second Gear Cage
29	1G6086	Third Main Gear
30	1P6210	Third Plant Gear (4)
30-1	1P3283	Third Gear Cage
31	1S2062	Internal Gear
32	4V1025	Front Housing
33	7S6003	Ball Bearing

Ref No	Part No	Description
34	2S6103	Retainer
35	7S2102	Ball (57)
36	3S5001	Pilot Pin
37	3S5214	Rear Clutch
38	6N2006	C Ring (2)
39	3S5219	Center Clutch
40	7S2112	Ball (4)
41	3S5221	End Clutch
43	3S5231	Ball Race
45	3S5021	Anvil
46	7S2105	Ball (2)
47	6N5110	Spring
48	3S2227	Slide Base
49	6N3007	Torque Spring
50	7S5121	Washer
51	2S2241	Anvil Bushing
52	3A5237	Clutch Housing
52-1	2Q2004	O Ring
53	6S2011	Needle Pin (3)
55	3A6007	Torque Ring
56	7S3107	Ball
57	6N2103	Spring
58	5S2001	Bit Slide Sleeve
59	6N2001	C Ring
60	5A3212	Housing Cap
61	5A6508	Torque Cover (Black)
61-1	5A6508-B	Torque Cover (Blue)
61-2	5A6508-G	Torque Cover (Gold)
61-3	5A6508-R	Torque Cover (Red)
61-4	5A6508-S	Torque Cover (Silver)
62	6S2006	Operation Rod
64	6S2021	Valve Plate
65	6N2104	Cone Spring
66	2Q5001	O Ring (3)
67	2S2011	Screw Cap (2)
70	2P3040	First Silencer
71	5L2201	Pistol Cover
73	2S2005	Air Inlet Bushing
74	2P3041	Second Silencer