



Ref No	Part No	Description
1	HPO02PGT-01	Valve Cap
2	HPO02PGT-02	O-Ring-Valve Cap
3	HPO02PGT-03	Valve Spring
4	HPO02PGT-04	Valve Stem
5	HPO02PGT-05	O-Ring-Valve Seat
5-1	HPO02PGT-05-1	O-Ring
6	HPO02PGT-06	Valvr Body
7	HPO02PGT-07	Throttle Lever
8	HPO02PGT-08	Roll Pin
9	HPO02PGT-09	Piston
10	HPO02PGT-10	Cylinder
11	HPO02PGT-11	O-Ring

Ref No	Part No	Description
12	HPO02PGT-12	O-Ring
13	HPO02PGT-13	Pistol Handle Houshing
15	HPO02PGT-15	Rubber Handle Grip
16	HPO02PGT-16	Anvil
17A	HPO02PGT-17A	Needle Holder 3mm
18A	HPO02PGT-18A	3mm Needle Set (19)
19	HPO02PGT-19	Spring Compression
20	HPO02PGT-20	Intermediate Tube
21	HPO02PGT-21	Front Tube
22	HPO02PGT-22	Cap Head Screw (2)
23	HPO02PGT-23	Washer (2)
24	HPO02PGT-24	Hex Wrench